

MARINE DIESEL

How much to use

	U.S. Customary			
	Standard Dose		Boost Dose	
	1:1200		1:600	
Gallons Fuel	fl oz	mL	fl oz	mL
10	1.1	32	2.1	63
15	1.6	47	3.2	95
20	2.1	63	4.3	126
25	2.7	79	5.3	158
30	3.2	95	6.4	189
35	3.7	110	7.5	221
40	4.3	126	8.5	252
45	4.8	142	9.6	284
50	5.3	158	10.7	315
55	5.9	173	11.7	347
60	6.4	189	12.8	378
65	6.9	205	13.9	410
70	7.5	221	14.9	442
75	8.0	237	16.0	473
80	8.5	252	17.1	505
85	9.1	268	18.1	536
90	9.6	284	19.2	568
95	10.1	300	20.3	599
100	10.7	315	21.3	631
105	11.2	331	22.4	662
110	11.7	347	23.5	694
115	12.3	363	24.5	725
120	12.8	378	25.6	757
125	13.3	394	26.7	789
130	13.9	410	27.7	820
135	14.4	426	28.8	852
140	14.9	442	29.9	883
145	15.5	457	30.9	915
150	16.0	473	32.0	946
160	17.1	505	34.1	1009
170	18.1	536	36.3	1072
180	19.2	568	38.4	1135
190	20.3	599	40.5	1199
200	21.3	631	42.7	1262
250	26.7	789	53.3	1577

Metric

	Standard Dose	Boost Dose	
	1:1200	1:600	
Liters Fuel	mL	mL	
40	33	67	
50	42	83	
60	50	100	
70	58	117	
80	67	133	
90	75	150	
100	83	167	
150	125	250	
200	167	333	
250	208	417	
300	250	500	
350	292	583	
400	333	667	
450	375	750	
500	417	833	
550	458	917	
600	500	1000	
650	542	1083	
700	583	1167	
750	625	1250	
800	667	1333	
850	708	1417	
900	750	1500	
950	792	1583	
1000	833	1667	
1100	917	1833	
1200	1000	2000	
1300	1083	2167	
1400	1167	2333	
1500	1250	2500	
1600	1333	2667	
1700	1417	2833	
1800	1500	3000	
1900	1583	3167	
2000	1667	3333	



Add directly to fuel tank. Marine diesel only.

As the quantities shown may be difficult to measure precisely, it's OK to be a little over or under; often close enough is good enough. There is no need to over-treat as this product is very concentrated – a little is good, but more is not necessarily better.